

3R Advantage Program

Packing & Shipping Instructions

IDEXX BioResearch recommends you use our sampling and shipping materials.
Email now to order your free materials idxxbioresearch-europe@idexx.com

Dry Ice Packing



- e Fill the polystyrene transport box with:

- Your samples
- Sufficient dry ice

Please include the NET amount of dry ice in KG's on the dry ice label.



- f Close the lid and tape up the box.



- g Stick the UN 3373 sticker on the box.

Make sure that the UN 3373 label remains visible at all the times.



- h Stick the dry ice sticker on the box. Make sure to write the amount of dry ice in the box.



- i Stick the waybill with the clear waybill bag on the box.

Make sure that the UN 3373 label remains visible at all the times.